



SYSTEM PRESSURE VALVE

FLUX VALVE

1	MOTOR
2	HEXANGULAR SCREW CAP
3	HANDLE
4	EXIT CONNECTOR
5	DOWN VALVE
6	VALVE (1PH)
7	CONNECTOR
8	FLOODING VALVE COVER
9	FLOODING VALVE
10	CENTER VALVE BOARD
11	GEAR PUMP
12	INNER HEXANGULAR SCREW
13	OIL BOX
14	SCREW

POWER UNIT EXPLODE PLOT

* Манометр не входит в комплект поставки гидравлического блока